

PARTS LIST

CAL. Y113A

| Cal. Y113A | | Cal. Y113A | |
|------------|--|--------------------|---|
| PART NO. | PART NAME | PART NO. | PART NAME |
| 125 755 | Train wheel bridge | 4002 755 | Coil block |
| 221 755 | Center wheel & pinion | 4146 755 | Step rotor |
| 231 755 | Third wheel & pinion | 4239 755 | Rotor stator |
| 241 755 | Fourth wheel & pinion | 4270 755 | Battery connection (-) |
| 261 755 | Minute wheel | 4271 755 | Battery connection (+) |
| 271 765 | Hour wheel | 022 247 | Train wheel bridge screw |
| 281 755 | Setting wheel | 022 247 | Battery connection (-) screw |
| 282 761 | Clutch wheel | 022 247 | Battery connection (+) screw |
| 354 765 | Winding stem | 022 247 | Setting lever spring screw |
| 383 755 | Setting lever | 022 248 | Date dial guard screw |
| 384 755 | Yoke | 011 325 | Upper hole jewel for fourth wheel |
| 388 765 | Setting lever spring | 011 547 | Lower hole jewel for step rotor |
| 391 755 | Second-setting lever | 011 568 | Upper hole jewel for step rotor |
| *470 605 | Day star with dial disk English + Spanish | 027 112 | Tube for train wheel bridge (A) |
| *470 606 | Day star with dial disk English + French | 027 113 | Tube for train wheel bridge (B) |
| *470 607 | Day star with dial disk English + Italian | 027 114 | Tube for battery connection (+) screw (A) |
| *470 608 | Day star with dial disk English + Japanese | 027 115 | Tube for battery connection (+) screw (B) |
| *470 609 | Day star with dial disk English + The Roman numerals | 027 116 | Tube for battery connection (+) screw (C) |
| *470 610 | Day star with dial disk English + Arabic | 027 117 | Tube for battery connection (+) screw (D) |
| *470 611 | Day star with dial disk English + German | 027 118 | Tube for setting lever spring |
| 701 755 | Fifth wheel & pinion | 027 119 | Tube for date dial guard screw |
| 719 755 | Day corrector | 027 120 | Tube for battery connection (-) screw |
| *801 622 | Date dial | 027 739 | Setting lever pin |
| 802 755 | Date driving wheel | 027 740 | Day corrector pin |
| 808 755 | Date dial guard | Maxell SR1120SW | Battery |
| 963 781 | Snap for day star with dial disk | SEIZAIKEN TR1120SW | |
| 4001 755 | Circuit block | | |

Remarks:

- ★ Day star with dial disk (Black figures on white background)
Used for both the crown and calendar frame at 3 o'clock position. If any other type of day star with dial disk is required, specify the number printed on the disk.
- ★ Date dial (801 622 black figures on white background)
Used for both the crown and calendar frame at 3 o'clock position. If any other type of date dial is required, specify 1) Cal. No. 2) The crown position 3) The calendar frame position and 4) Dial No.