

CERTINA

Pièces de rechange
Spare parts
Piezas de recambio
Ersatzteile
Pezzi di ricambio

Cal. 15-20

$6\frac{3}{4}'''$ | \varnothing 15,30 mm H. : 4,60 mm AUT — 32 R 19800 Ah



1:1											
166	169	169/1	180/2	182	195	200	210				
220	240	250	260	300/2	301/1	324	3241				
3251	3242	3243	3244	325	3252	358	364	400			
401	404	407	410	415	420	422	424	430			
435	440	443	445	450	454	498/1	705				
710	714	721	724	730/1	736	738	771				
2:1											
5105 (2x)	5125	5166 (2x)	5415	5420	5424	5445	5738	5750 (2x)			
601	602	605 606	610	611	615	616	620	621	646	647	648

CERTINA

Liste des pièces de rechange
Spare part list
 Lista de las piezas de recambio
Liste der Ersatzteile
 Elenco dei pezzi di ricambio

Cal. 15-20

Pièce No. <i>Part No.</i> Pieza No. <i>Ersatzteil No.</i> Pezzo No.	Calibre de base <i>Basic calibre</i> Calibre de base <i>Grundkaliber</i> Calibro di base	Pièce No. <i>Part No.</i> Pieza No. <i>Ersatzteil No.</i> Pezzo No.	Calibre de base <i>Basic calibre</i> Calibre de base <i>Grundkaliber</i> Calibro di base	Vis <i>Screws</i>	Tornillos <i>Schrauben</i>	Viti
				Pièce No. <i>Part No.</i> Pieza No. <i>Ersatzteil No.</i> Pezzo No.	Calibre de base <i>Basic calibre</i> Calibre de base <i>Grundkaliber</i> Calibro di base	
166 (2×)	15-20	410	15-20	5105 (2×)		13-20
169 (4×)	13-20 C	415	15-20	5110 (2×)		= No. 5105
169/1 (2×)	13-20 L	420	15-20	5121		= No. 5105
180/2	15-20	422	15-20	5125		15-20
195	15-20	424	15-20	5166 (2×)		17-25
200	15-20	430	15-20	5415		248
210	15-20	435	15-20	5420		15-20
220	15-20	440	15-20	5424		15-20
240	15-20	443	15-20	5445		15-20
250	15-20	445	15-20	5738		370
260	15-20	450	15-20	5750		15-20
300/2	13-20	454	15-20			
301/1	12-10	498/1	15-20			
324	17-25	705	15-20	<i>Pierres</i> <i>Jewels</i>	<i>Piedras</i> <i>Steine</i>	<i>Pietre</i>
3241 (2×)	12-10	710	15-20	601		15-20
3242	300	714	15-20	602		15-20
3243	12-10	721	15-20	605		15-20
3244	12-10	724	15-20	606		= No. 605
325	17-25	730/1	15-20	610		12-10
3252	300			611		15-20
358	13-20			615		12-10
364	15-20			616		230
				620		12-10
401	15-20			621		15-20
404	15-20					
407	15-20					

CERTINA

Pièces de rechange pour dispositifs automatiques
Spare parts for self-winding devices
Piezas de recambio para los dispos. autom.
Ersatzteile für Automat-Vorrichtung
Pezzi di ricambio per dispositivi automatici

Cal. 15-20

1:1



1142



1143



1481



1482



1520



1520/1

2:1



51142
(2x)



1624
1625



1643
1644



8534
8534/1



8535
8535/1

CERTINA

Liste des pièces de rechange pour dispositifs autom.

Spare part list for self-winding devices

Lista de las piezas de recambio para los disp. autom.

Liste der Ersatzteile für Automat-Vorrichtungen

Elenco dei pezzi di ricambio per dispositivi autom.

Cal. 15-20

Pièce No. <i>Part No.</i> Pieza No. <i>Ersatzteil No.</i> Pezzo No.	Calibre de base <i>Basic calibre</i> Calibre de base <i>Grundkaliber</i> Calibro di base		Vis <i>Screws</i>	Tornillos <i>Schrauben</i>	Viti
			Pièce No: <i>Part No.</i> Pieza No. <i>Ersatzteil No.</i> Pezzo No.	Calibre de base <i>Basic calibre</i> Calibre de base <i>Grundkaliber</i> Calibro di base	
1142	15-20		51142 (2×)	= No. 5105	13-20
1143	15-20				
1481	15-20				
1482	15-20				
1520	15-20				
1520/1	15-20				
			Pierres <i>Jewels</i>	Piedras <i>Steine</i>	Pietre
			1624	15-20	
			1625	= No. 1624	
			1643	15-20	
			1644	= No. 1643	
			8534	15-20	
			8535	15-20	
			8534/1	= No. 8534	
			8535/1	= No. 8535	