




1 Tag-Geh- u. Weckerwerk m. Etui-Druck-Lichtschalter, 1 Schlüssel
1 day alarm movement with case light switch, 1 key
Mouvement réveil 1 jour, cadran illuminable par touche à l'étui,
1 clef
Mecanismo de sonería, 1 día, esfera iluminable por toque al
estuche, 1 llave

Werk
Movement **007**
Mouvement **027**
Máquina



07 - 80 - 201.1

203



07 - 80 - 201/1.1

204



06 - 202.1

198



06 - 203.1

199




06 - 204.1

200




07 - 210.1

205




07 - 200.1

206



07 - 200 - 80 - 211.1

207




07 - 200 - 214.1

208



0459 - 7.1

209



0459 - 8.1

210



0459 - 21

211