





Elektronisches Geh- und Weckerwerk 3 Hz
Electronic time and alarm movement 3 Hz
Mouvement réveil électronique 3 Hz
Mecanismo y sonería electrónicos 3 Hz

Werk **100**
Movement **110**
Mouvement **110**
Máquina




231 - 80 - 1

501



231 - 80 - 1

502



231 - 80 - 10

503



230 - 2

504



230 - 3

505



230 - 4

506




230 - 5

507



230 - 6

508



230 - 6 - 2

509



230 - 7

510



230 - 8

511



06 - 203

199



230 - 80 - 9

512



101 - 128

228



101 - 122

231



101 - 121

232



230 - 80 - 14

513

Werk
Movement **100**
Mouvement **110**
Máquina

Elektronisches Geh- und Weckerwerk 3 Hz
Electronic time and alarm movement 3 Hz
Mouvement réveil électronique 3 Hz
Mecanismo y sonería electrónicos 3 Hz



231 - 12

514




230 - 52

515



230 - 11

516



231 - 80 - 30

517



00 - 80 - 36

102



00 - 80 - 38

103



231 - 80 - 25

518



230 - 27

519



230 - 37

520




231 - 80 - 22

521




231 - 24

522



231 - 80 - 15

523




231 - 20

524




231 - 13

525



230 - 80 - 35

526




230 - 33

527



230 - 32

528




230 - 34

529



00 - 8.1

135



231 - 80 - 38

530



231 - 39

531



230 - 40

532



230 - 41

533



Elektronisches Geh- und Weckerwerk 3 Hz
Electronic time and alarm movement 3 Hz
Mouvement réveil électronique 3 Hz
Mecanismo y sonería electrónicos 3 Hz

Werk **100**
Movement **110**
Mouvement **110**
Máquina



101 - 21/1

63



230 - 80 - 42

534



230 - 58

535



230 - 43 - 1

536



231 - 213

538




231 - 212

539



0560 - 11

540



231 - 90 - 1

537

231 - 90 - 2

559




303 - 21

241



230 - 50

541



230 - 51 - 1

542



93 - 12

543



230 - 80 - 46

544




101 - 93/1.1

48

Werk
Movement **100**
Mouvement **110**
Máquina

Elektronisches Geh- und Weckerwerk 3 Hz
Electronic time and alarm movement 3 Hz
Mouvement réveil électronique 3 Hz
Mecanismo y sonería electrónicos 3 Hz



5001 - 80 - 3

545



230 - 53

546



101 - 96

558



5000 - 40

547



04 - 175/1

174



230 - 44

548




230 - 45

549




301 - 13/1.1

57



5000 - 80 - 7

550



5003 - 80 - 7

551



Elektronisches Geh- und Weckerwerk 3 Hz
Electronic time and alarm movement 3 Hz
Mouvement réveil électronique 3 Hz
Mecanismo y sonería electrónicos 3 Hz

Werk **100**
Movement **110**
Mouvement **110**
Máquina



5000 - 10

552



5000 - 21 - 1

553



208 - 26

78



231 - 47

554



5000 - 21

555




301 - 200/Ms Ra

556




5000 - 77/vg Ra

557



5001 - 51

568



5001 - 51 - 1

569



233 - 2

571




230 - 35

572



233 - 80 - 14

573



233 - 234

570



101/125/1

230



0560 - 11

575



208 - 26 - 1.2

78




233 - 80 - 9

574


Werk
Movement **100**
Mouvement **110**
Máquina

Elektronisches Geh- und Weckerwerk 3 Hz
Electronic time and alarm movement 3 Hz
Mouvement réveil électronique 3 Hz
Mecanismo y sonería electrónicos 3 Hz




233 - 80 - 1

560




233 - 80 - 1-1

561



233 - 90 - 1

562




233 - 90 - 254

563




5001 - 10

567




5001 - 80 - 7

564



5012 - 80 - 7

565



5001 - 7 - 1

566