





Elektronisches Geh- und Weckerwerk
Electronic time and alarm movement
Mouvement réveil électronique
Mecanismo y sonería electrónicos

Werk
Movement
Mouvement
Máquina


128




730




732




731




733




734



706



735




736



737



718



738



713



739



740



720