

# Calibre 1556

Ø28.50mm  
Ht: 7.03mm  
Train: 19.800

- Automatic
- Date and Day of the Week
- Centre Seconds
- Shock Proof
- 26 Jewels

## Base Calibre 1530












Image	Rolex No.	Description
	126	Bridle
	127	Bridle
	130	Bridle
	170	Screw for bridle
	5093	Calendar wheel nut
	7957	Screw for date jumper
	7960	Screw for date indicator seating
	7967	Calendar wheel
	7968	Star wheel assembled
	7969	Finger for date
	7978	Screw for stud holder

















Image	Rolex No.	Description
	7981	Screw for regulating the balance
 	8001	Centre wheel with cannon pinion
	8002	Centre second pinion ht. 6.26mm
	8004	Cannon pinion ht. 3.40mm
 	8005	Hour wheel with double tothing ht. 2.46mm
	8006	Yoke for cam
	8007	Jewel for yoke for cam
	8008	Spring for cam yoke
 	8009	Unlocking yoke cam
	8011	Stud for cam
	8012	Date jumper
	8012-1	Date jumper stud
	8013	Day jumper









Image	Rolex No.	Description
	8015	Date indicator seating
	8016-1	Date indicator: champagne
	8016-2	silvered
	8016-101	champagne arabic
	8016-201	silvered arabic
	8016-102	champagne chinese
	8016-202	silvered chinese
	8017-101	Day indicator: champagne, english
	8017-102	champagne, spanish
	8017-103	champagne, french
	8017-104	champagne, italian
	8017-105	champagne, german
	8017-106	champagne, danish
	8017-107	champagne, swedish

Image	Rolex No.	Description
	8017-108	champagne, japanese
	8017-110	champagne, arabic
	8017-112	champagne, chinese
	8017-114	champagne, portuguese
	8017-115	champagne, indonesian
	8017-117	champagne, ethiopian
	8017-119	champagne, hebrew
	8017-121	champagne, finnish
	8017-122	champagne, dutch
	8017-123	champagne, norwegian
	8017-124	champagne, russian
	8017-126	champagne, persian
	8017-129	champagne, catalan
	8017-130	champagne, maroccan
	8017-132	champagne, turkish
8017-133	champagne, latin	
8017-134	champagne, greek	
	8017-201	Day indicator: silvered, english
	8017-202	silvered, spanish
	8017-203	silvered, french
	8017-204	silvered, italian
	8017-205	silvered, german
	8017-206	silvered, danish
	8017-207	silvered, wedish
	8017-208	silvered, japanese
	8017-210	silvered, arabic
	8017-212	silvered, chinese
	8017-214	silvered, portuguese
	8017-215	silvered, indonesian
	8017-217	silvered, ethiopian
	8017-219	silvered, hebrew
	8017-221	silvered, finnish
















Image	Rolex No.	Description
	8017-222	silvered, dutch
	8017-223	silvered, norwegian
	8017-224	silvered, russian
	8017-226	silvered, persian
	8017-229	silvered, catalan
	8017-230	silvered, maroccan
	8017-232	silvered, turkish
	8017-233	silvered, latin
	8017-234	silvered, greek
	8027	Set of screws
	8028	Automatic device upper bridge
	8029	Automatic device module
	8050	Second wheel
	8051	Escape wheel, 26 jewels
	8065	Shock-absorber for balance-upper
	8074	Screw for balance stop spring

Image	Rolex No.	Description
	8076	Bush for center wheel-lower
	8102	Balance bridge
	8103	Stud support with small plate
	8106	Balance with Breguet hairspring, timed
	8108	Screw for balance
	8115	Balance stop spring
	8118	Main plate
	55051	Screw for stud